

FIRE CONTROL

Fire Extinguishers:

Fire extinguishers are obviously displayed within the lodge. Know where they are and be prepared to use them if required.

With most fires the extinguishers will prove to be quicker and more effective than the fire hoses. The use of extinguishers must, therefore, be given top priority.

Fire Hoses:

Two internal fire hoses are provided:

1. Beneath the kitchen servery
2. In cupboard at the end of the Bedroom Corridor

An external fire hose is also provided. It is located in the external cabinet to the rear of the Drying Room. The key to the cabinet is located in the Ski Room adjacent to the Entrance Door.

The external fire hose is to be used in conjunction with the fire hydrant located approximately 10 metres up the hill from the rear of the Lodge.

To operate the hydrant the following procedure should be followed:

1. Connect fire hose and unroll
2. Close valve with small handle (drain valve) - turn clockwise
3. Open valve with large handle (control valve) - turn anti-clockwise
4. After use the drain valve must be left open. Turn fully anti-clockwise to prevent water freezing in and damaging the hydrant. Drain hose and dry completely before rolling up.

Fire Exit:

On emergency fire exit is located in the bathroom of Bedroom 6.

Smoking:

Smoking in Bedrooms is not permitted - please co-operate with this rule.